



RE-TIRE PROTECTIVE COATING OPTIONS

Re-Tire requires a protective coating.

There are 3 approved protective coating for Re-Tire: Hilway Direct, Carefree Matte and Dr. Schutz (all available from Capri).

Hilway Direct and Carefree Matte are Mop on Acrylic Sealers. Mop on acrylic sealers are the conventional and most familiar method for sealing rubber floors. Most maintenance crews can apply these.

- Easily applied with a string mop.
- Most can be “buffed” to renew their luster.
- Can be chemically stripped from the floor and re-applied.
- Mop on sealers have worked well in many types of installations for years.
- Familiarity for maintenance staff and may also be used on other resilient flooring in the installation.
- Lower initial cost.
- Higher maintenance costs over the life of the floor.

Dr. Schutz is a 2 component water-based Urethane Finish. This is the “premium” coating option. Dr. Schutz is available as Waxnomor, Marknomor and Slipnomor additive. Waxnomor is for general use heavy traffic areas. Marknomor is also for heavy use areas but offers extra chemical resistance. Marknomor is recommended in medical facilities, hair salons, or automotive showrooms etc. The Slipnomor additive can be combined with Waxnomor if increased slip resistance is desired.

- Extremely durable finish.
- Regular cleaning with mop and neutral cleaner.
- No stripping required.
- Lightly abrade to re-coat.
- Re-coat every 1-3 years depending on usage.
- Application technique is easy to learn.
- Increased chemical resistance (Marknomor).
- Increased slip resistance (Slipnomor additive).
- Higher initial cost.
- Lower maintenance costs over the life of the floor.

For more info specific information and recommendations contact Capri technical department.